

SEER3000SPOT	31CH Mode1	25CH Mode2	DMX Value	FUNCTION
Dimmer	1	1	0---255	Brightness--->Darkness
Dimmer Fine	2		0---255	
Strobe	3	2	0---3	Closed
			4---103	Slow Strobe--->Fast Strobe
			104---107	Open
			108---207	SlowPuls---->Fast Puls
			208---212	Open
			213---225	Random Slow Strobe
			226---238	Random Medium Strobe
			239---251	Random Fast Strobe
252---255	Open			
Color	4	3	0---7	White
			8---14	White + Color1
			15---21	Color1
			22---29	Color1 + Color2
			30---36	Color2
			37---44	Color2 + Color3
			45---51	Color3
			52---59	Color3 + Color4
			60---66	Color4
			67---74	Color4 + Color5
			75---81	Color5
			82---89	Color5 + Color6
			90---96	Color6
			97---104	Color6 + Color7
			105---111	Color7
			112---119	Color7 + Color8
			120---126	Color8
			127---127	Color8 + Color9
128---191	CW Rotating Slow---Fast			
192---255	CCW Rotating Fast---Slow			
Cyan	5	4	0---255	EXCLUDED---->INSERTED
Magenta	6	5	0---255	EXCLUDED---->INSERTED
Yellow	7	6	0---255	EXCLUDED---->INSERTED
CTC	8	7	0---255	EXCLUDED---->INSERTED
Macro Color	9		0---255	
IRIS	10	8	0---128	MAX---MIN
			129---131	Close
			132---171	Slow Puls----Fast Puls
			172---211	Slow Puls Fast Close-----Fast Puls Fast Close
			212---251	Slow Puls Fast Open-----Fast

			252---255	Puls Fast Open Open
Gobo1 Select	11	9	0---10 11---20 21---30 31---40 41---50 51---60 61---70 71---80 81---100 101---120 121---140 141---160 161---180 181---200 201---220 221---237 238---255	White Gobo1 Gobo2 Gobo3 Gobo4 Gobo5 Gobo6 Gobo7 Gobo1 Shake Slow----Fast Gobo2 Shake Slow----Fast Gobo3 Shake Slow----Fast Gobo4 Shake Slow----Fast Gobo5 Shake Slow----Fast Gobo6 Shake Slow----Fast Gobo7 Shake Slow----Fast CW Rotation Slow---Fast CCW Rotation Fast---Slow
Gobo1 Index Rotation	12	10	0---127 128---191 192---255	0° ----360° (FINE IN 13CH) CW Rotating Slow---Fast CCW Rotation Fast---Slow
Gobo1 Index Rotation FINE	13		0---255	
Gobo2 Select	14	11	0---10 11---20 21---30 31---40 41---50 51---60 61---70 71---80 81---100 101---120 121---140 141---160 161---180 181---200 201---220 221---237 238---255	White Gobo1 Gobo2 Gobo3 Gobo4 Gobo5 Gobo6 Gobo7 Gobo1 Shake Slow----Fast Gobo2 Shake Slow----Fast Gobo3 Shake Slow----Fast Gobo4 Shake Slow----Fast Gobo5 Shake Slow----Fast Gobo6 Shake Slow----Fast Gobo7 Shake Slow----Fast CW Rotation Slow---Fast CCW Rotation Fast---Slow
Gobo2 Index Rotation	15	12	0---127 128---191 192---255	0° ----360° (FINE IN 16CH) CW Rotating Slow---Fast CCW Rotation Fast---Slow

Gobo2 Index Rotation FINE	16		0---255	
Gobo3(Fixed Gobo)	17	13	0---6 7---13 14---20 21---27 28---34 35---41 42---48 49---54 55---61 62---68 69---79 80---95 96--- 111 112---127 128---143 144---159 160--- 175 176--- 191 192--- 207 208--- 223 224---239 240---247 248--- 255	White Gobo1 Gobo2 Gobo3 Gobo4 Gobo5 Gobo6 Gobo7 Gobo8 Gobo9 Gobo10 Gobo1 Shake Slow---->Fast Gobo2 Shake Slow---->Fast Gobo3 Shake Slow---->Fast Gobo4 Shake Slow---->Fast Gobo5 Shake Slow---->Fast Gobo6 Shake Slow---->Fast Gobo7 Shake Slow---->Fast Gobo8 Shake Slow---->Fast Gobo9 Shake Slow---->Fast Gobo10 Shake Slow---->Fast CW Rotation Slow---->Fast CCW Rotation Fast---->Slow
Prism	18	14	0---127 128---255	EXCLUDED INSERTED
PrismRotation	19	15	0---127 128---191 192---255	Position 0° ---->360° CW Rotation Slow----Fast CCW Rotation Fast----Slow
Forst	20	16	0---255	EXCLUDED-----INSERTED
Focus	21	17	0---255	
Focus FINE	22		0---255	
Zoom	23	18	0---255	
Zoom FINE	24		0---255	
PAN(X)	25	19	0---255	
PAN(X) FINE	26	20	0---255	
TILTE(Y)	27	21	0---255	
TILTE(Y) FINE	28	22	0---255	
P/T SPEED	29	23	0---128 129---170 171---211 212---255 252---255	Fastest----->Slowest SlowSpeed (1/3 MaxSpeed) MediumSpeed (1/2 MaxSped) Fast Speed (Fastest Speed) Blackout when moving

Lamp Control	30	24	0---32 33---64 65---96 97---128 129---160 161---193 194---225 226---255	Undefined LAMP OFF(> 3s) Undefined LAMP ON(> 3s) Undefined LOW POWER(> 3s) Undefined FULL POWER(> 3s)
Control	31	25	0---127 128---153 154---179 180---205 206---231 232---255	Undefined Undefined Undefined Undefined Undefined Reset ALL(> 3s)

*NOTE:关闭灯泡后，请勿立即又打开灯泡，请等待大于 2 分钟之后再点灯泡。如果无法点亮灯泡，试试给灯泡一次“关灯泡”信号，然后再去点灯泡。