
















































ARES-S3A 1.01	19CH Mode1	17CH Mode2	DMX Value	Funciton
Dimmer	1	1	0---255	Darkness----->Bright
Dimmer FINE	2		0---255	
Strobe	3	2	0---3 4---103 104---107 108---207 208---212 213---225 226---238 239---251 252---255	Closed Slow Strobe--->Fast Strobe Open Slow Pulsation--->Fast Pulsation Open Random Slow Strobe Random Medium Strobe Random Fast Strobe Open
Color1	4	3	0---9 10---19 20--- 29 30--- 39 40---49 50---59 60---69 70---79 80---89 90--99 100--- 109 110---119 120---129 130---139 140---149 150---159 160-- 207 208---255	White  Color1+White  Color1  Color1 + Color2  Color2  Color2 + Color3  Color3  Color3 + Color4  Color4  Color4 + Color5  Color5  Color5 + Color6  Color6  Color6 + Color7  Color7  Color7 + WHITE  CW Rotation Slow--->Fast CCW Rotation Fast--->Slow
Color2	5	4	0---9 10---19 20--- 29	White Color1+White 

			<p>30--- 39 40---49 50---59 60---69 70---79 80---89 90--99 100--- 109 110---119 120---129 130---139 140---149 150---159 160-- 207 208---255</p>	<p>Color1 </p> <p>Color1 + Color2 </p> <p>Color2 </p> <p>Color2 + Color3 </p> <p>Color3 </p> <p>Color3 + Color4 </p> <p>Color4 </p> <p>Color4 + Color5 </p> <p>Color5 </p> <p>Color5 + Color6 </p> <p>Color6 </p> <p>Color6 + Color7 </p> <p>Color7 </p> <p>Color7 + WHITE </p> <p>CW Rotation Slow--->Fast 中速 CCW Rotation Fast--->Slow 低速</p>
Gobo1(Fixed Gobo)	6	5	<p>0---3 4---7 8---11 12---15 16---19 20---23 24---27 28---31 32---35 36---76 77---80 81---121 122---138 139---155 156---172 173---189 190---206</p>	<p>WHITE </p> <p>GOBO 1 </p> <p>GOBO 2 </p> <p>GOBO 3 </p> <p>GOBO 4 </p> <p>GOBO 5 </p> <p>GOBO 6 </p> <p>GOBO 7 </p> <p>GOBO 8 </p> <p>CW SlowRotation----->FastRotation WHITE</p>

			207---223 224---230 231---255	CCW SlowRotation-----> FastRotation GOBO 1 Shake Slow---->Fast GOBO 2 Shake Slow---->Fast GOBO 3 Shake Slow---->Fast GOBO 4 Shake Slow---->Fast GOBO 5 Shake Slow---->Fast GOBO 6 Shake Slow---->Fast GOBO 7 Shake Slow---->Fast GOBO 8 Shake Slow---->Fast
Gobo2 Select	7	6	0---7 8--- 15 16---23 24--- 31 32--- 39 40--- 47 48---59 60---80 81---101 102--- 122 123--- 143 144---164 165---189 190--- 222 223--- 255	WHITE GOBO 1  GOBO 2  GOBO 3  GOBO 4  GOBO 5  GOBO 6  GOBO 1 Shake Slow---->Fast GOBO 2 Shake Slow---->Fast GOBO 3 Shake Slow---->Fast GOBO 4 Shake Slow---->Fast GOBO 5 Shake Slow---->Fast GOBO 6 Shake Slow---->Fast CW SlowRotation----->FastRotation CCW SlowRotation-----> FastRotation
Gobo2 Index Rotation	8	7	0---127 128---191 192---255	Position 0° ---->360° (FINE in CH8) CW SlowRotation-----> FastRotation CCW SlowRotation----->FastRotation
Gobo2 Index Rotation FINE	9		0---255	GOBO2 index Rotation FINE
PRISM	10	8	0---127 128--255	EXCLUDED INSERTED 
PRISM Rotation	11	9	0---127 128---190 191---194 195---255	Position 0° ---->360° CW FastRotation-----> SlowRotation STOP CCW Slow Rotation----->Fast Rotation
FOCUS	12	10	0---255	
ZOOM	13	11	0---255	

PAN(X)	14	12	0---255	
PAN(X) FINE	15	13	0---255	
TILTE(Y)	16	14	0---255	
TILTE(Y) FINE	17	15	0---255	
P/T SPEED	18	16	0---128 129---170 171---211 212---255	Fastest----->Slowest Slow Speed (1/3 MaxSpeed) Medium Speed (1/2 MaxSpeed) Fast Speed (Fastest Speed)
Control	19	17	0---127 128--255	Undefined Reset ALL